

Mouthpiece adapter – Differences between the mouthpiece shanks

There are basically 2 widespread variants: 0 Morse (USA) and the European shank (e. g. Tilz). So, our mouthpiece adapters are marked with "M" and "T".

It is not important how deep the mouthpiece sits in the lead pipe, but where the end of the mouthpiece is in the lead pipe. This means, that a mouthpiece is sitting different in different lead pipes, but still ends at the "right place". A Tilz mouthpiece for example is sitting 22mm deep in a Dürk lead pipe and in a S. W. Lewis lead pipe 20mm deep. Please use for the following horn models the correct adapter:

Model	European Mouthpiece Cone (T)	USA Mouthpiece Cone (M)
D1	T	M
D2	T	M
D3	T	M
D3 Radek Baborak	T	M
D4	T	M
D8	T	M
D10 Allegrini	T	M
ab Aeternum	T	M
LDx5	TL (L=Lewis-lead pipe)	ML (L=Lewis-lead pipe)
LDx6	T	M
LD Clevenger	TL (L=Lewis-lead pipe)	ML (L=Lewis-lead pipe)

As the mouthpieces are not always absolutely identical, we also have adapters which allow, that the mouthpiece sits slightly deeper in the lead pipe. These are marked with "1" or "1,5". Thus, the "1" goes deeper 1mm and the "1,5" 1.5mm deeper into the tube mouth.

Please try to find the correct adapter for your mouthpiece by trying.